



Nunawading Feeder (4 poles)
 supplied by United Energy
 Zone Substation
 Not to scale - for
 presentation purposes only

See inset for this area

Not to scale - for
 presentation purposes only

SP AusNet Supply Areas

ESSENTIAL SERVICES COMMISSION

- **Zone Substations**
-> Indicates a zone spread across more than one geographic area
- White areas represent locations not supplied electricity by SP AusNet

All features displayed on this map are indicative only, supply areas illustrated are approximate.